


# Starbright Twitter Reader

## Installation

1. Download
2. Extract the .zip contents
3. Run StarbrightTwitter.exe
4. Create a Twitter user account for use with the display.
5. Set the auto update time to 1 mins
6. Click Update from Twitter



## Auto Update

Sets the time period to wait before checking new messages and scrolling back in time.

## Remote Mode

Use the remote to change messages instead of automatically changing.  
The most recent message is looped until 0 - 9 or A - F is pressed on the remote.

## Clear Queue

Clears the message queue and display.

## Next Group

Moves to the next message group in non-remote mode.  
In remote mode, this acts the same as Update from Twitter..

Noritake Co., Inc.  
Electronics Division Headquarter  
2635 Clearbrook Drive  
Arlington Heights, IL 60005  
Toll free: (800) 779 - 5846  
Phone: (847) 439 - 9020  
support.ele@noritake.com  
www.noritake-elec.com

East Coast  
**New Jersey Branch**  
15-22 Fair Lawn Ave.  
Fair Lawn, NJ 07410  
Toll free: (888) 296 - 3423  
Phone: (201) 475 - 5200  
Fax: (201) 796 - 2269

Midwest, Canada, and Mexico  
**Chicago Branch**  
2635 Clearbrook Dr.  
Arlington Heights, IL 60005  
Toll free: (800) 779 - 5846  
Phone: (847) 439 - 9020  
Fax: (847) 593 - 2285

West Coast  
**Los Angeles Branch**  
21081 S. Western Ave. Ste 180  
Torrance, CA 90501  
Toll free: (888) 795 - 3423  
Phone: (310) 320 - 1700  
Fax: (310) 320 - 2900