


Starbright Messenger

Installation

1. Download
2. Extract the .zip contents
3. Run StarbrightMessenger.exe
4. Type in your messages one-per-line into the box; They will be shown one after another
5. Select the display action
6. Select another folder to start a new message group
7. Press Send to display



Scroll On, Scroll Off

Scrolls the message in from right to left, pauses 2 seconds and scrolls it off.

Clear, Scroll On

The previous message disappears and the message is scrolled in from right to left.

Clear, Immediate

Clears the screen and immediately display the entire message.

If the message is longer than 21 characters, this action should not be used.

Immediate w/o Clearing

Immediately displays a message.

Use this action to prevent blinking when there's only one message in the folder.

If the message is longer than 21 characters, this action should not be used.

Noritake Co., Inc.
Electronics Division Headquarter
2635 Clearbrook Drive
Arlington Heights, IL 60005
Toll free: (800) 779 - 5846
Phone: (847) 439 - 9020
support.ele@noritake.com
www.noritake-elec.com

East Coast
New Jersey Branch
15-22 Fair Lawn Ave.
Fair Lawn, NJ 07410
Toll free: (888) 296 - 3423
Phone: (201) 475 - 5200
Fax: (201) 796 - 2269

Midwest, Canada, and Mexico
Chicago Branch
2635 Clearbrook Dr.
Arlington Heights, IL 60005
Toll free: (800) 779 - 5846
Phone: (847) 439 - 9020
Fax: (847) 593 - 2285

West Coast
Los Angeles Branch
21081 S. Western Ave. Ste 180
Torrance, CA 90501
Toll free: (888) 795 - 3423
Phone: (310) 320 - 1700
Fax: (310) 320 - 2900